PX AND PXN TYPE WIRELINE PLUGS

PRODUCT 30-093 AND 30-094

The *TechWest PX Type Plug* is a positive blank off tool designed to be run into an X Type Profile Nipple, holding pressure from both above and below.

The *TechWest PXN Type Plug* is a similar tool, designed to be run into an XN Type Bottom No-Go Nipple, holding pressure from both above and below.

OPERATION

Two wireline trips are required to set the PX and PXN Type Plugs.

The first trip involves locking the plug body into the nipple. Since the by-pass ports are exposed during this operation, the plug body remains in an equalized state. Once the plug body is properly installed in the nipple, the prong is run into the plug body. This blanks off the ports.

To pull the plug the prong must first be pulled to allow equalization to occur. Once equalized, the plug body is retrieved from the nipple.



techwesttools.com